

WASHING MACHINE INSTRUCTIONS

REGULAR/COTTON CYCLE

① SORT ITEMS INTO 5 CATEGORIES

① COLORED CLOTHES



② WHITE CLOTHES




③ TABLE CLOTHS



④ TOWELS & ROBES



⑤ SHEETS & DUVETS



② EMPTY POCKETS, TREAT STAINS & ADD DETERGENT

① EMPTY POCKETS



② SPRAY 'N WASH



③ KIRKLAND DETERGENT



CHLORINE BLEACH



FABRIC SOFTENER



③ SET WASHING MACHINE CYCLE TO REGULAR-WARM

